



MANUALE BREVE PER LE TELECAMERE SF-CV037H-4W /SF-IPDM820AH-4W

PROCEDERE COME SEGUE:

ACCENDERE IL WIFI DELLA RETE E CONOSCERNE LA PASSWORD

1 INSTALLARE L'APPLICAZIONE SAFIRE CONNECT

2 AVVIARE L'APPLICAZIONE E PREMERE IL SIMBOLO + IN ALTO A DESTRA

3 SCEGLIRE AGGIUNTA MANUALE

4 VI SARA' RICHiesto IL NUMERO SERIALE DELLA TELECAMERA DA AGGIUNGERE (VEDI ANCHE ETICHETTE)

5 PER LA TELECAMERA 1 (ESEMPIO) SN D18311850 MENTRE LA PASSWORD adminBKOHLX (VI SARA' RICHiesta DOPO)

6 PER LA TELECAMERA 2 (ESEMPIO) SN D18311875 MENTRE LA PASSWORD adminYHFBQZ (VI SARA' RICHiesta DOPO)

7 VI VIENE CHIESTO DI FARE LA CONNESIONE ALLA RETE, ACCETTARE

8 NELLA MASCHERA DELLE TELECAMERE SCEGLIERE (TELECAMERA WIRELESS POI OK)

9 VIENE RICHiesta LA PASSWORD

10 RICORDARE DI ABILITARE AUDIO

DA PC INVECE CON INTERNET EXPLORER DIGITARE L'INDIRIZZO DELLA TELECAMERA SOLITAMENTE 192.168.1.64 E UTILIZZARE COME ID admin E PASSWORD admin+codice verifica

A screenshot of a web-based login interface. It features two input fields: the first for the username 'admin' and the second for the password 'adminK0XLX'. A lock icon is visible on the password field, and an eye icon is used to toggle password visibility. Below the fields is a link for 'Password dimenticata?' and a blue 'Accesso' button.